

Catchbox Pro User Manual

Quick Start

1. Setup a compatible 3rd party transmitter and receiver pair, syncing the two units and connecting the receiver to a sound system. For specific instructions, see the relevant user manual provided by the manufacturer of said system.
2. Choose an adapter cable based on the brand and model of your 3rd party transmitter and connect it to the microphone input of said transmitter.
3. Remove the Catchbox Pro Module from the outer cover by twisting the cylinder 90 degrees and pulling upwards.
4. Open the velcro strap surrounding the device by pulling it gently along the surface of the module.
5. Install one AA battery into the back part of the Catchbox Pro Module.
6. Connect the 3rd party transmitter to the Catchbox Pro Module by plugging the RCA male end of the adapter cable into the RCA female connector, located inside the front cavity of the Catchbox Pro Module.
7. Place the transmitter inside the cavity of the Catchbox Pro Module making sure no antennas or cables are protruding outwards.
8. Turn on both the 3rd party transmitter and the muting circuit located at the back of the Catchbox Pro Module.
9. Secure the velcro strap tightly around the Catchbox Pro Module, ensuring that both the battery located at the back as well as the frontal cavity are covered by the velcro strap.
10. Place the Catchbox Pro Module inside the cover, making sure to align the magnetic locking mechanisms of both the cover and the Catchbox Pro Module. See visual marks for guidance.
11. Test the volume level by speaking into the microphone and adjusting it using the volume controls on the 3rd party transmitter or receiver.